

Product Overview

AND/OR is a recycled rubber & cork flooring product that is comprised of a unique blend of both post-consumer and post-industrial recycled products. Ethylene Propylene Diene Monomer (EPDM) Rubber and cork granules combine to create a wide variety of

colors and patterns. AND/OR is available in a wide variety of thicknesses, from 3.2mm to 9mm, as a square-edge tile, an interlocking tile or as a roll. AND/OR is ideal for commercial offices, educational facilities, corporate gyms and other areas where a durable, flexible and sustainable

product is needed. AND/OR is FloorScore certified and is manufactured in the USA.

Features

- **Manufactured From Recycled Material (Pre & Post Consumer)**
- **Shock & Impact Resistance**
- **Superior Slip Resistance**
- **Excellent Durability**
- **Excellent Sound Reduction**
- **Soft & Supportive Under Foot**
- **Qualifies for LEED® Credits**
- **FloorScore® Certified**
- **Declare™ Labeled, Red List Free**
- **CA Section 01350 Complaint**

Technical Data

Tile Dimensions:	12" x 24"*, 24" x 24"
Standard Roll Width:	4'
Standard Roll Length:	25' - 80' (depending on thickness)
Thicknesses:	3.2mm, 4mm, 6mm, 8mm, 9mm
Weight / Sq. Ft.:	1 - 3.8 lbs. (depending on thickness)
Finish:	Textured
ASTM F137 - Flexibility:	Passes
ASTM F970 - Static Load Limit:	Passes, 250 lbs.
ASTM F2199 - Dimensional Stability:	Passes, <0.05 in. Change
ASTM F1514 - Color Heat Stability:	Passes, ΔE<8
ASTM F925 - Chemical Resistance:	Passes (chart available)
ASTM D2240 - Hardness:	85, Shore A
ASTM E648 (NFPA 253) - Critical Radiant Flux:	Class I, >0.45 W/cm²
ASTM E662 (NFPA 258) - Smoke Density:	Passes, <450
ASTM CAN/ULC - Fire Rating:	90 (FSR), 215 (SDC)
ASTM D2047 - Slip Resistance:	>1.0 (wet & dry)
ASTM E492/E989 - Impact Sound:	IIC 56*
ASTM E90 / E413 - Airborne Sound:	STC 54**
CHPS / CA Section 01350:	Compliant
LBC Red List 3.0 Chemicals:	None
Pre-Consumer Recycled Content:	5% - 31.8% (depending on color)
Post-Consumer Recycled Content:	4.5% - 85% (depending on color)
Acclimation Time:	48 Hours
Storage & Acclimation Conditions:	65° - 85° F
	+ Square-Edge Only
	* 6" Concrete, Drop Ceiling
	** Wood/Gypsum I-Joist System

Additional Information

Approved Adhesives

Capri RC1000 Acrylic Adhesive
Capri AR4000 Urethane Adhesive

Approved Finishes

Loba InvisibleProtect

Custom Options

Capri AND/OR can be customized to match other colors, sizes and thicknesses

by request. Minimum quantities vary depending on format and thickness - contact a sales agent or e-mail sales@capricollections.com for more information.

Size & Packaging

3.2 mm

Square-Edge Tile Size: **12" x 24",
24" x 24"**
 Interlocking Tile Size: **24" x 24"**
 Standard Roll Size: **4' x 25'-80'**
 Standard Roll Area: **100-320 sq. ft.**
 Weight / Sq. Ft.: **1 lbs.**
 Max Tiles / Skid: **600 (12" x 24")
300 (24" x 24")**
 Max Rolls / Skid: **6**

4 mm

Square-Edge Tile Size: **12" x 24",
24" x 24"**
 Interlocking Tile Size: **24" x 24"**
 Roll Size: **4' x 25'-60'**
 Roll Area: **100-240 sq. ft.**
 Weight / Sq. Ft.: **1.3 lbs.**
 Max Tiles / Skid: **600 (12" x 24")
300 (24" x 24")**
 Max Rolls / Skid: **6**

6 mm

Square-Edge Tile Size: **12" x 24",
24" x 24"**
 Interlocking Tile Size: **24" x 24"**
 Roll Size: **4' x 25'-50'**
 Roll Area: **100-200 sq. ft.**
 Weight / Sq. Ft.: **1.9 lbs.**
 Max Tiles / Skid: **420 (12" x 24")
210 (24" x 24")**
 Max Rolls / Skid: **6**

8 mm

Square-Edge Tile Size: **12" x 24",
24" x 24"**
 Interlocking Tile Size: **24" x 24"**
 Roll Size: **4' x 25'-35'**
 Roll Area: **100-140 sq. ft.**
 Weight / Sq. Ft.: **2.7 lbs.**
 Max Tiles / Skid: **300 (12" x 24")
150 (24" x 24")**
 Max Rolls / Skid: **6**

9 mm

Square-Edge Tile Size: **12" x 24",
24" x 24"**
 Interlocking Tile Size: **24" x 24"**
 Roll Size: **4' x 25'-35'**
 Roll Area: **100-140 sq. ft.**
 Weight / Sq. Ft.: **2.85 lbs.**
 Max Tiles / Skid: **300 (12" x 24")
150 (24" x 24")**
 Max Rolls / Skid: **6**

1. PRE-INSTALLATION

- Consult all associated technical data for all related products and procedures, including adhesive, maintenance and warranty documents, prior to installation.
- Allow all trades to complete work prior to installation.
- Deliver all materials to the installation location in their original packaging with labels intact.
- Do not stack pallets to avoid damage.
- Remove all plastic and strapping from product after delivery and inspect for visible or obvious damage.
- Unroll all rolled material and allow to relax for at least 24 hours prior to installation.
- Ensure that all adhesives intended for installation are approved for use with flooring material.
- Ensure installation area and material storage conditions are between 65° F (19° C) and 85° F (30° C) for at least 48 hours before, during and after

installation.

- Ensure HVAC system is operational and fully functioning at normal operating conditions.
- Protect installation area from extreme climate changes, such as heat, freezing, humidity, and direct sunlight, for at least 48 hours prior, during and 48 hours after installation.
- Ensure all substrate preparation requirements have been performed, read and/or understood by all interested parties.
- Do not proceed with installation until all conditions have been met.

2. PRODUCT LIMITATIONS

Do not install materials directly over LVT, cushioned vinyl, hardwood flooring, cork flooring, rubber flooring or asphaltic materials. Do not install flooring materials outdoors, in and around commercial kitchens or areas that may be exposed to animal or vegetable fats and oils or petroleum-based hydrocarbons. Do not install in areas that may be subjected to sharp, pointed objects, such

as spikes. When installing in areas that may be exposed to ice skates, ensure skate guards are worn. When installing material in outdoor areas, entry areas, areas that may be exposed to topical moisture or areas that will experiencing heavy usage, rolling loads or weight, ensure a heavy duty indoor/outdoor adhesive, such as the Capri AR4000, is used. Do not allow product to be directly exposed to extreme heat sources, such as radiators, ovens or other high-heat equipment. Do not install in areas that may be exposed to repeated and sustained UV light, as product may fade or discolor. Material may be susceptible to staining from rubber tires, casters or rubber-backed walk-off mats, as well as harsh disinfectants, cleaning agents, dyes or other harsh chemicals – ensure all chemicals and materials that may come in contact with flooring surface will not stain, mar or otherwise damage the flooring material prior to use.

3. SUBSTRATE PREPARATION

All substrates must be prepared according to ASTM F710, as well as all other applicable ASTM, ACI and RFCI

guidelines. Substrates must clean, smooth, permanently dry, flat, and structurally sound. Substrates must be free of visible water or moisture, dust, sealers, paint, sweeping compounds, curing compounds, residual adhesives and adhesive removers, concrete hardeners or densifiers, solvents, wax, oil, grease, asphalt, visible alkaline salts or excessive efflorescence, mold, mildew and all other extraneous coating, film, material or foreign matter.

All substrates must have all existing adhesives, incompatible materials, contaminants or bond-breakers mechanically removed via scraping, sanding or grinding prior to adhesive installation. In extreme situations, shotblasting may be required. Mechanical preparation must expose at least 90% of the original substrate. Following cleaning and removal, all substrates must be vacuumed with a flat vacuum attachment or damp mopped with clean, potable water to remove all surface dust. **Sweeping without vacuuming or damp mopping will not be acceptable.**

All porous substrates must be tested per ASTM F3191 to confirm porosity. All substrates that do not meet porosity requirements are considered non-porous. Ensure that all non-porous substrates are not contaminated with aforementioned contaminants and that all installation guidelines for non-porous substrates are followed. It is recommended that all substrates have a floor flatness of FF32 and/or a flatness tolerance of 1/8" in 6' or 3/16" in 10'. Substrates that do not meet this requirement should have a compatible cementitious patch or self-leveling underlayment installed to flatten the installation area.

Do not use solvent/citrus based adhesive removers prior to installation. Follow The Resilient Floor Covering Institute's (RFCI) "Recommended Work Practice for Removal of Existing Floor Covering and Adhesive", and all applicable local, state, federal and industry regulations and guidelines. When removing asbestos and asbestos containing materials, follow all applicable OSHA standards.

CEMENTITIOUS SUBSTRATES

All cementitious substrates, including

self-leveling underlayments, must have a minimum compressive strength of 3000 PSI and be prepared in accordance with ASTM F710 and ACI 302.2R. When flooring is being installed directly over concrete, surfaces that have an ICRI Concrete Surface Profile (CSP) of 5 or more should be smoothed with a self-leveling underlayment or a cementitious patch to prevent imperfections from telegraphing through flooring materials. On or below grade concrete must have a permanent, effective moisture vapor retarder installed below the slab.

New or existing concrete substrates on all grade levels must be tested in accordance with ASTM F2170, using in situ Probes, to quantitatively determine relative humidity no more than one week prior to the installation.

Moisture Limits

Capri RC1000 Acrylic Adhesive

- 85% RH
- 5 lbs. MVER

Capri AR4000 Urethane Adhesive

- 85% RH
- 5 lbs. MVER

Interlocking Tile Installation

- 85% RH
- 5 lbs. MVER

In addition to ASTM F2170 Relative Humidity Testing, existing concrete that has previously had floor covering installed on all grade levels must be tested in accordance with ASTM F1869, using Calcium Chloride test kits, to quantitatively determine the Moisture Vapor Emissions Rate (MVER) of the concrete.

If ASTM F2170 or ASTM F1869 test results exceed the prescribed limits, a moisture mitigation product must be installed prior to proceeding with installation. Do not install flooring until moisture testing has been conducted per the appropriate standard and/or moisture mitigation has been installed and is dry to the touch. Do not install flooring in below grade areas when hydrostatic pressure is visible or suspected.

LIGHTWEIGHT/GYPSUM SUBSTRATES

Lightweight or gypsum substrates must have a minimum compressive strength of 2000 PSI when installed over a wood substrate or 3000 PSI when installed over a concrete substrate. Lightweight or gypsum substrates must be installed and prepared in accordance with ASTM F2419 or ASTM F2471, respectively. Lightweight or gypsum substrates that do not meet these requirements should be strengthened with a compatible repair product to improve the compressive strength of the substrate. Substrate must be structurally sound and firmly bonded to subfloor. All cracked or fractured areas must be removed and repaired with a compatible repair product. New or existing substrates may require a sealant or primer be installed prior to resilient floor installation. Follow the substrate manufacturer's recommendations regarding preparation for resilient flooring.

WOOD SUBSTRATES

Wood substrates must be compliant with and prepared in accordance with ASTM F1482. Wood substrates should be of double layer construction with a recommended total thickness of 1" or more (depending on federal, state and local building codes). For standard installations, the top layer must be an APA Underlayment Grade plywood or equivalent with a minimum thickness of 1/4". Plywood must be smooth, free of knots or voids and fully sanded. When floors may be subjected to moisture, use an APA approved exterior grade plywood. Other wood subfloor materials, such as CDX, OSB, lauan, particleboard, chipboard, fiberboard or cementitious tile backer boards, are not acceptable substrates. Do not use preservative-treated and fire-retardant plywood, as some may be manufactured with resins or adhesives that may cause discoloration or staining of the flooring. Do not install flooring directly over solid or engineered hardwood flooring without first installing plywood or a suitable cementitious repair product at a minimum thickness of 1/4" over the hardwood flooring.

Wood subfloor deflection, movement,

or instability may cause the flooring installations to release, buckle or deform. As such, do not use a plastic or resin filler to patch cracks. Do not use cement or rosin coated nails and staples or solvent-based construction adhesives to adhere the plywood. Do not install resilient flooring directly over a sleeper system (wood subfloor over concrete) or Sturd-I-Floor panels.

RESINOUS SUBSTRATES

When installing directly over a resinous products, such as an epoxy coating, ensure the coating is dry to the touch and has cured for the prescribed length of time. Substrate must be clean, dry, sound and free of contaminates. Be sure to follow adhesive installation procedures and trowel sizes for non-porous substrates. This may require abrasion of the resinous coating.

METAL SUBSTRATES

Metal substrates must be thoroughly sanded/ground to remove all residue, oil, rust and/or oxidation. Substrate must be smooth, flat and sound prior to installation. When installing in areas that may be subject to topical water, moisture and/or high humidity, an anti-corrosive coating should be applied to protect metal substrate. Contact a local paint or coating supplier for coating recommendations. Install flooring material within 12 hours after sanding/grinding to prevent re-oxidation. Deflection in the metal floor can cause a bond failure between the adhesive and the metal substrate. Be sure to follow installation procedures and trowel sizes for non-porous substrates.

EXISTING FLOORING SUBSTRATES

The suitability of existing flooring as a substrate depends on the specific requirements of the adhesive being used to install the material. As such, refer to the adhesive requirements for existing flooring substrates and ensure all adhesive requirements and guidelines are followed.

RADIANT HEATING SUBSTRATES

When installing flooring over a substrate that contains a radiant heating system, ensure the radiant heat is no higher

than 70° F (21° C) 48 hours prior to and during the entire installation. 48 hours after installation, the radiant heat may be gradually increased over the course of 24 hours, until normal operating temperature is reached. Ensure the temperature of the radiant heating system does not exceed 85° F (29.5° C) and avoid making abrupt changes in radiant heating temperature.

4. CONSTRUCTION JOINTS & CRACKS

All cracks, construction joints and other voids, as well as the areas surrounding them, must be clean and free of dust, dirt, debris and contaminants. All minor cracks 3/64" wide or less must be repaired with a compatible cementitious patch.

Due to the dynamic nature of concrete, manufacturer cannot warranty installations directly over construction joints (such as control cuts or saw joints), expansion joints, cracks or other voids wider than 3/64". Construction joints, expansion joints or cracks wider than 3/64" must have a suitable crack repair or joint repair system installed per the below recommendations.

All expansion joints should have a suitable expansion joint covering system installed to allow for expansion and contraction of the joint. To treat expansions joints where an expansion joint covering system can't be installed or to treat through cracks (depth at least 75% of the thickness of the concrete), chase joint or crack with a suitable saw or grinder and open to a minimum width of 1/4". Be sure to clean all dust, dirt and debris from crack. Joints and cracks should then be sealed with a suitable, elastomeric caulk designed for use in expansion joints. Install a closed-cell backer rod at prescribed depth and follow all caulk manufacturer's instructions for installation. Ensure surface is troweled flush with surface of concrete.

To treat construction joints and surface cracks over 3/64", chase joint or void with a suitable saw or grinder and clean all dust, dirt and debris from crack. Fill entire crack with a rigid crack treatment designed for use in construction joints or cracks. Follow material manufacturer's instructions for installation. Ensure surface is troweled flush with surface of

concrete.

Consult a project engineer or architect prior to treating cracks or joints, especially those that may affect structural integrity (such as expansion joints). Review all manufacturer installation instructions and/or consult manufacturer technical staff for all crack or joint filling products prior to treating construction joints and cracks.

5. INTERLOCKING TILE INSTALLATION

Ensure substrate is suitably prepared prior to installation, as manufacturer is not responsible for substrates that have not been properly prepared and tested for moisture. Indoor installations of interlocking tile are recommended to be loose-laid without adhesive. All outdoor installations of interlocking tile require a full spread of an indoor/outdoor waterproof adhesive; see Section 6 for installation instructions.

Ensure substrate is clean, dry and sound prior to installation. Square installation area using the 3-4-5 squaring rule or similar method to establish initial installation starting line.

Some flooring products, colors and textures have latent and acceptable color and shade variations. Inspect material prior to and during installation to verify that there are no visible defects, damages or excessive shading variations. If there are concerns regarding shade or color variation, **do not** install material and consult sales agent and manufacturer's technical staff.

Whenever possible, avoid installing flooring seams directly over seams in the substrate. Borders and perimeter pieces should be no less than half the width of the tile and should be no less than 1/8" from the wall, depending on depth of wall base or trim, to allow for expansion.

Borders and other specialty cut tiles should be undercut to fit loosely against thresholds, transition strips, fixtures, door jambs or other obstacles; forcing incorrectly sized tiles into smaller areas will cause the tile to buckle.


Roll material with a 3 section, 75 lb. roller within 30 minutes of installation, crossing in a perpendicular direction after initial

roll. **Rollers heavier than 75 lbs. could cause tiles to stretch or shift.** Use a hand roller in areas that cannot be reached with larger roller. Visually inspect installation to ensure that material has not shifted and all seams are tight and flat.

To finish open edges of interlocking tile or areas intended to butt against another flooring material, use a straight edge and a utility knife to remove male ends of tile and install appropriate finishing accessory.

6. GLUE-DOWN TILE INSTALLATION

Ensure substrate is clean, dry, flat, sound and suitably prepared prior to installation, as manufacturer is not responsible for substrates that have not been properly prepared and tested for moisture. Ensure adhesive is approved for use with flooring material and the proper trowel type and size is used, as manufacturer is not responsible for all adhesion issues related to improper adhesive selection or usage.



Prior to installation, confirm material installation pattern and direction per design specifications or work order. AND/OR tile should be installed in an ashlar or brick pattern to ensure tight seams and

an overall ideal visual appearance.

Inspect all tiles prior to and during installation to verify that there are no visible defects, damages or excessive shading variations. Some flooring products, colors and textures have latent and acceptable color and shade variations. If there are concerns regarding shade or color variation, do not install material and consult a sales representative and manufacturer's technical staff. **Material installed with obvious visual defects will not be covered under warranty.**

Square the room using the 3-4-5 squaring rule or similar method to establish and mark initial installation starting line. Dry-lay several tiles to establish an ideal installation layout, ensuring perimeter tiles are as equal in size as possible. Ensure material around perimeter is 1/8" from wall or less, depending on depth of wall base or trim. Pre-cut borders and other specialty pieces to fit snugly against or around walls, thresholds, transition strips, fixtures and other protrusions or accessories. Avoid forcing material tightly against vertical surfaces, as material may buckle.

Apply adhesive according to instructions for the specific product in use and observe adhesive flash times, if applicable. Pay close attention to adhesive working times and flash times to avoid adhesion issues. This may require working in smaller sections. Be sure to follow instructions based on substrate porosity (porous or non-porous).

Adhesive Spread Rates

Capri+ RC-1000 Acrylic Adhesive

- Porous: 125-150 sq. ft. / gallon
- Non-Porous: N/A

Capri+ AR-4000 Urethane Adhesive

- Porous: 125-150 sq. ft. / gallon
- Non-Porous: 125-150 sq. ft. / gallon

When installing into wet adhesive, avoid walking or working on material until adhesive has cured for light foot traffic. **Working on material that is installed into wet adhesive could cause adhesive to displace.** When working off of material is not possible, use a kneeling board or equivalent to disperse weight evenly and

prevent adhesive displacement.

Roll material with a 3 section, 75 lb. roller within 30 minutes of installation, crossing in a perpendicular direction after initial roll. **Rollers heavier than 75 lbs. could cause tiles to stretch or shift.** Use a hand roller in areas that cannot be reached with larger roller.

Periodically lift material to ensure there is proper adhesive transfer and ensure adhesive has not surpassed the open time – adhesive should cover 90% of material. Replace trowels at recommended intervals to maintain proper trowel ridge and spread rate.

Visually inspect installation to ensure that material has not shifted and that adhesive has not been squeezed out of joints or compressed onto surface. Clean excessive adhesive or adhesive residue from the surface of the material per adhesive recommendations. **Do not use mineral oils to clean flooring materials, as material may become permanently discolored.** Do not apply abrasive or solvent based cleaners directly to material.


7. ROLL PREPARATION

Ensure roll has been unrolled and relaxed for at least 24 hours prior to installation, in order to prevent roll memory and curling. Inspect each roll of material prior to installation to verify that there are no visible defects, damages or excessive shading variations. Some flooring products, colors and textures have latent and acceptable color and shade variations. If there are concerns regarding shade or color variation, do not install material and consult a sales representative and manufacturer's technical staff. **Material installed with obvious visual defects will not be covered under warranty.**

Ensure substrate is clean, dry and sound prior to installation. Square the room using the 3-4-5 squaring rule or similar method to establish and mark initial installation starting line. Measure and determine room layout and seam location prior to cutting material.

Roll material is labeled in sequence alphabetically on each side. As such, material should be cut and installed

in sequence (see below). For example, roll A-B should be installed adjacent to B-C, ensuring that the B edges are butted together whenever possible. Ensure seams have a consistent visual appearance at edges so that color variations blend as seamlessly as possible - this may require flipping rolls to get the ideal color distribution from the edge of one roll to the other. **Failure to follow correct roll sequencing could cause gapping or excessive shade variation at seams.**



Overlap seams by $\sim 1/16"$ to ensure tight seams during final installation. Horizontal seams must be staggered by 6' – 10' (depending on room size and roll length) and must be cut prior to installing material with adhesive. Ensure flooring seams do not directly overlap seams in substrate.

Ensure material around perimeter is $1/8"$ from wall or less, depending on depth of wall base or trim. Cut borders and other specialty pieces to fit snugly against or around walls, thresholds, transition strips, fixtures and other protrusions or accessories. Avoid forcing material tightly against vertical surfaces, as material may buckle. Allow material to relax and acclimate for 24 hours prior to installation.

8. ROLL INSTALLATION

Ensure substrate is clean, dry, flat, sound and suitably prepared prior to installation, as manufacturer is not responsible for

substrates that have not been properly prepared and tested for moisture. Ensure adhesive is approved for use with flooring material and the proper trowel type and size is used, as manufacturer is not responsible for all adhesion issues related to improper adhesive selection or usage.

Ensure all seams are cut and laid out per Section 7. Inspect seam transitions to ensure that color is consistent and seam is hardly visible. Once all seams have been cut and material has relaxed and acclimated, carefully fold back half of material and apply adhesive according to instructions for specific product in use. Once adhesive has been applied and flashed, carefully roll material back into adhesive to avoid trapping air between the adhesive bed and the material. If adhesive is oozing out of seams or material is shifting excessively, adhesive may be too wet for installation. Review open times and allow adhesive to flash longer prior to installing material into adhesive and remove adhesive from material immediately.

Do not work on material that is installed into wet adhesive, as this could displace adhesive. **Working on material that is installed into wet adhesive could cause adhesive to displace.** When working off of material is not possible, use a kneeling board or equivalent to disperse weight evenly and prevent adhesive displacement.

Roll installation area with a 3 section, 75 lb. roller within 30 minutes of installation, crossing in a perpendicular direction after initial roll. Re-roll material 30 minutes after initial roll. Clean excessive adhesive or adhesive residue from the surface of the material according to adhesive instructions.

Periodically lift material to ensure proper adhesive transfer and ensure adhesive has not surpassed the open time – adhesive should cover 90% of material. Pay close attention to open times and flash times to avoid adhesion issues. This may require installing material in smaller sections. Replace trowels and applicators at recommended intervals to maintain proper trowel ridge and spread rate.

To ensure tight seams and prevent

movement, dust, dirt, debris and topical moisture from getting into seams, tape all seams together after installation using a residue-free releasable tape that is intended for flooring and hard surfaces (such as 3M multi-surface "blue" tape).

Material towards the inside end of the roll may have minor edge-lifting and curling on end seams or butted seams – if this is evident after installation, use weight to weigh down edges.

Visually inspect installation to ensure that material has not shifted and that adhesive has not been squeezed out of joints or compressed onto surface. Clean excessive adhesive or adhesive residue from the surface of the material per adhesive recommendations. **Do not use mineral oils to clean flooring materials, as material may become permanently discolored.** Do not apply abrasive or solvent based cleaners directly to material.

9. INITIAL MAINTENANCE

Ensure that adhesive has cured for recommended period of time prior to conducting initial maintenance. Remove all protective coverings prior to cleaning. Sweep or dust mop and vacuum flooring to remove all dirt, dust or debris.

Mix 6 - 7 oz. of Capri Neutral Cleaner per gallon of warm and clean potable water (1:20) and use a clean mop to apply cleaning solution to area. Let solution stand for 5-10 minutes.

Using a low-speed (180 – 360 RPM) floor buffer or swing single disc scrubber, Scrub the floor while wet using a 22 gauge soft bristled scrubbing brush or a 3M 4100 White Polishin Pad. If flooring is heavily soiled, an additional cleaning may be required.

Use a wet vacuum or clean mop to remove all excess cleaning solution. Rinse area with clean, cool water and ensure that all cleaning residue has been removed (this may require additional rinsing). Allow area to dry completely before allowing foot traffic.

To ease maintenance and protect the surface of the material, AND/OR must have a floor finish installed following installation and initial maintenance.

For additional information regarding maintenance, please see the associated Care & Maintenance document.

10. INITIAL FINISH APPLICATION

Ensure that initial maintenance has been conducted prior to applying floor finish. Flooring area must be free of dust, dirt, debris, adhesive or cleaning residues and any potential contaminants. Ensure that HVAC is operation - installation area and flooring material must be between 60° and 75° F during application and curing. Avoid direct forced air, drafts and direct sunlight during application and curing. **Do not** dilute finish or apply to surfaces below 50° F.

Loba InvisibleProtect is a two-component product. Shake both components of InvisibleProtect vigorously prior to mixing. Add Part B directly to Part A, reseal and shake vigorously to mix both components together. Once mixed, pour the finish into a clean paint tray or plastic-lined bucket for application.

If possible, application should start at the primary light source and work away from it, in order to make finish imperfections (such as puddles, skips and voids) easier to identify and correct. Use a 120g microfiber roller (available from Capri) or equivalent to apply the finish in a thin, even coat. Following initial roll, re-roll finish in a perpendicular direction. Avoid puddles, pooling, skips and voids - correct imperfections as quickly as possible during application. Prevent all foot traffic, dust and debris from entering the area and allow material to cure for a minimum of 2 hours.

Once the first coat has cured initially, apply the second coat of Loba InvisibleProtect as above **within 24 hours**. Allow the finish to cure for 12 hours before allowing light foot traffic. Do not resume normal use for 24-48 hours. Finish will fully cure in 7 days - avoid objects which could scratch or damage the floor until the finish has fully cured.

For additional information regarding

the finish and finish application, please see the product Care & Maintenance document.

11. FLOORING PROTECTION

Protect newly installed flooring with construction grade paper or protective boards, such as Masonite or Ram Board, to protect flooring from damage by other trades. Do not slide or drag pallets or heavy equipment across the new flooring. Limit usage and foot traffic according to the adhesive's requirements. When moving appliances or heavy furniture, protect flooring from scuffing and tearing using temporary floor protection.

All furniture casters or glides must be intended for resilient flooring and made of a soft material (such as a rubber or poly-based material). Casters and glides must have a flat contact point that is at least 1" sq. in. or 1.125 in. in diameter to limit indentation and flooring or finish damage. All rolling seating in desk areas must have a resilient flooring chair pad installed over the finished floor to protect floor covering.

All fixed furniture legs or corners must have permanent felt or soft rubber floor protectors installed on all contact points to reduce indentation, wear, scratching and other flooring or finish damage. Floor protectors must have a flat contact point of at least 1 sq. in. or 1.125 in. diameter and must cover the entire bottom surface of the furniture leg.

Ensure all furniture castors and chair legs and are clean and free of all dirt and debris. Routinely clean chair castors and furniture legs to ensure that dirt or debris has not built up or become embedded in castors or floor protectors. Replace chair castors and floor protectors at regular intervals, especially if they become damaged or heavily soiled.

Place walk-off mats at outside entrances. Prevent water and moisture from accumulating underneath walk-off mats. Ensure mats are manufactured with non-staining backs to prevent discoloration.

12. WARRANTY

Capri provides a Limited 10 Year Warranty for all Mediterra cork tile. For additional information, see associated warranty documents.

FOR PROFESSIONAL USE ONLY. PLEASE CAREFULLY REVIEW ALL ASSOCIATED TECHNICAL DATA SHEETS, SAFETY DATA SHEETS, MAINTENANCE DOCUMENTS AND WARRANTY INFORMATION PRIOR TO INSTALLATION.